



NOTES:

1. Minimum vertical flashing height of 8.0" above the field membrane must be achieved.
2. Fully adhered systems require InnovatiBond Membrane Adhesive between membrane and insulation.
3. Termination not shown in this drawing; use appropriate termination.
4. Apply InnovatiSeal TPO Edge Sealant at all cut or exposed membrane edges

BASE FLASHING WITH CANT

BA-3