



- NOTES:
1. REFER TO [IKO.COM/COMM](http://IKO.COM/COMM) FOR THE MOST UP TO DATE INSTALLATION INFORMATION.
  2. ANY CARPENTRY OR METAL WORK SHOULD BE DESIGNED AND CONSTRUCTED IN ACCORDANCE WITH LOCAL CODE REQUIREMENTS AND/OR PROJECT SPECIFICATIONS. THESE COMPONENTS SHOULD BE REVIEWED AND APPROVED BY A LICENSED DESIGN PROFESSIONAL. IKO ASSUMES NO RESPONSIBILITY FOR THE INSTALLATION OF THE ASSOCIATED COMPONENTS OR DAMAGE TO THE ROOF SYSTEM DUE TO FAULTY INSTALLATION.
  3. WOOD BLOCKING MUST BE EMBEDDED IN A LAYER OF IKO INNOVISEAL GP SEALANT PRIOR TO FLASHING.
  4. FOR MECHANICALLY ATTACHED SYSTEMS, INSTALL A MINIMUM OF FOUR (4) INNOVIFAST FASTENERS AND SEAM PLATES TO SECURE THE ROOFING MEMBRANE AT THE BASE OF THE I-BEAM.
  5. APPLY INNOVISEAL TPO EDGE SEALANT AT ALL CUT OR EXPOSED MEMBRANE EDGES.

IKO INNOVIFAST TPO UNIVERSAL CORNER

IKO INNOVI TPO MEMBRANE

IKO INNOVISEAL TPO EDGE SEALANT CONTINUOUS BEAD AROUND FLASHING (NOT SHOWN FOR CLARITY)

Title: I-BEAM FLASHING

Detail Number: T-P-9

Issue Date: 8/01/2025

Maximum Warranty Term: 30-Years

Not to Scale



**COMMERCIAL**

Specify with Confidence.

