



NOTES:

1. REFER TO IKO.COM/COMM FOR THE MOST UP TO DATE INSTALLATION INFORMATION.
2. ANY CARPENTRY OR METAL WORK SHOULD BE DESIGNED AND CONSTRUCTED IN ACCORDANCE WITH LOCAL CODE REQUIREMENTS AND/OR PROJECT SPECIFICATIONS. THESE COMPONENTS SHOULD BE REVIEWED AND APPROVED BY A LICENSED DESIGN PROFESSIONAL. IKO ASSUMES NO RESPONSIBILITY FOR THE INSTALLATION OF THE ASSOCIATED COMPONENTS OR DAMAGE TO THE ROOF SYSTEM DUE TO FAULTY INSTALLATION.
3. REFER TO EXISTING ROOFING MANUFACTURERS' SPECIFICATIONS FOR SURFACE PREPARATION PROCEDURES.
4. CONSTRUCT AND ANCHOR DRIP EDGE IN ACCORDANCE WITH SMACNA RECOMMENDATIONS.
5. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES.
6. FLANGE OF THE METAL DRIP EDGE MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/2" (13 MM) FROM WOOD EDGE.
7. CONTACT IKO TECHNICAL DEPARTMENT FOR BALLASTED ROOF SYSTEMS.

Title: DRIP EDGE WITH TPO COATED METAL

Detail Number: **T-RE-4**

Issue Date: 8/01/2025

Maximum Warranty Term: 30-Years

Not to Scale



COMMERCIAL

Specify with Confidence.

