



**NOTES:**

1. REFER TO [IKO.COM/COMM](http://IKO.COM/COMM) FOR THE MOST UP TO DATE INSTALLATION INFORMATION.
2. ANY CARPENTRY OR METAL WORK SHOULD BE DESIGNED AND CONSTRUCTED IN ACCORDANCE WITH LOCAL CODE REQUIREMENTS AND/OR PROJECT SPECIFICATIONS. THESE COMPONENTS SHOULD BE REVIEWED AND APPROVED BY A LICENSED DESIGN PROFESSIONAL. IKO ASSUMES NO RESPONSIBILITY FOR THE INSTALLATION OF THE ASSOCIATED COMPONENTS OR DAMAGE TO THE ROOF SYSTEM DUE TO FAULTY INSTALLATION.
3. WALKWAY PADS MUST BE INSTALLED AT ALL ROOF ACCESS POINTS.
4. CLEAN MEMBRANE SURFACE WITH TPO MEMBRANE CLEANER PRIOR TO WALKWAY PAD INSTALLATION.
5. DO NOT INSTALL WALKWAY PADS OVER MEMBRANE SEAMS.
6. ALL IKO TPO MEMBRANE ADHESIVES ARE APPROVED FOR ADHERING THE WALKWAY PAD TO THE MEMBRANE.

Title: TPO WALKWAY PADS OVER TPO MEMBRANES

Detail Number: **T-WP-1**

Issue Date: 8/01/2025

Maximum Warranty Term: 30-years

Not to Scale



**COMMERCIAL**

Specify with Confidence.

