



NOTES:

1. Minimum vertical flashing height of 8.0" above the field membrane must be achieved.
2. Fully adhered systems require InnoviBond Membrane Adhesive between membrane and insulation.
3. Termination not shown in this drawing; use appropriate termination.
4. Apply InnoviSeal TPO Edge Sealant at all cut or exposed membrane edges

BASE FLASHING - HORIZONTAL ATTACHMENT

BA-2