



# InnoviBoot<sup>TM</sup>

## TPO Universal Pipe Boot

**Stock #:** 6200060, 6200170, 6200173

**Material:** 60-mil, injection-grade, weldable IKO InnoviTPO

**Standard size:** 1 in. (26 mm), 2 in. (50.8 mm), 3 in. (76.2 mm), 4 in. (101.6 mm), 5 in. (127 mm), 6 in. (152.4 mm)

**Colors:** White, Grey, Tan

**Packaging:** 10/box, 7.5 lbs. (3.4 kg)/box

All reported values are nominal.

- Ideal penetration flashing for a wide range of round penetrations.
- Stepped rib design makes sizing simple and holds the clamp securely.
- Factory fabrication ensures quality.

### System Compatibility

InnoviBoot TPO Universal Pipe Boots are intended for use with IKO InnoviTPO Roofing Systems and are approved for use with an appropriate IKO Diamond Shield Limited Warranty. Building owners, specifiers, roof consultants and roofing contractors are invited to review the IKO InnoviTPO System Specifications at [www.iko.com/innovi](http://www.iko.com/innovi) for further information on including this product as part of a complete IKO roofing system.

### Truly Universal

InnoviBoot TPO Universal Pipe Boots are made from 60-mil non-reinforced TPO and fit many different penetrations on the roof, making them an ideal flashing for many demanding roofing applications. Field installation is as easy as heat-welding the TPO Universal Pipe Boot to the roofing membrane and attaching the provided stainless steel hose clamp to secure the collar around the penetration. The injection-molded, stepped rib design keeps the ring clamp in place and makes cutting for sizing quick and easy.

### Top Quality

Factory fabrication under strict quality manufacturing controls makes the InnoviBoot TPO Universal Pipe Boots ideal for quality control for the entire roofing installation. A contractor can save significant fabrication time, resulting in considerable labor savings.



## InnoviBoot<sup>TM</sup> TPO Universal Pipe Boot

### Installation

1. Prepare all welding surfaces by cleaning with InnovPrime<sup>TM</sup> TPO Pre-Wash.
2. Cut pipe boot at rib to the desired diameter as illustrated on the base flange of the boot.
3. Place the boot over the penetration and pull down until base flange meets the field membrane.
4. Mark the penetration around the top of the boot and then remove.
5. Apply InnovSeal<sup>TM</sup> Water Stop Mastic around the penetration just under the mark made in the previous step.
6. Replace the boot over the penetration and heat-weld the base flange to the membrane.
7. Secure the ring clamp below the highest rib at the top of the boot and tighten until secure.
8. NOTE: Certain conditions require application of a target patch over the penetration area, with 4 fasteners and plates installed in the field membrane around the penetration. See Standard Details for more information.

The information on this sheet is based on data supplied by the manufacturer to IKO and believed to be true and accurate. The information is offered solely for the user's consideration, investigation and verification. Nothing contained herein constitutes or represents a warranty or guarantee for which the manufacturer or the distributor can be held legally responsible.