



- NOTES:
1. REFER TO IKO.COM/COMM FOR THE MOST UP TO DATE INSTALLATION INFORMATION.
  2. ANY CARPENTRY OR METAL WORK SHOULD BE DESIGNED AND CONSTRUCTED IN ACCORDANCE WITH LOCAL CODE REQUIREMENTS AND/OR PROJECT SPECIFICATIONS. THESE COMPONENTS SHOULD BE REVIEWED AND APPROVED BY A LICENSED DESIGN PROFESSIONAL. IKO ASSUMES NO RESPONSIBILITY FOR THE INSTALLATION OF THE ASSOCIATED COMPONENTS OR DAMAGE TO THE ROOF SYSTEM DUE TO FAULTY INSTALLATION.
  3. STANDARD IKO INNOVIFLASH SQUARE SPLIT PIPE BOOT SIZES ARE 2" AND 4".
  4. HOLD CLAMP ADJUSTMENT SCREW AT CENTER OF SIDE OF COLUMN, 1/8" DOWN FROM TOP OF FLASHING. TIGHTLY FORM STRAP AROUND 90-DEGREE CORNER AND REPEAT FOR THE OTHER 3 CORNERS WHILE KEEPING STRAP TIGHT, FEED STRAP END INTO ADJUSTMENT SCREW AND TIGHTEN. ENSURE 1/8" OF FLASHING IS EXPOSED ABOVE STRAP.
  5. FOR MECHANICALLY ATTACHED SYSTEMS, INSTALL A MINIMUM OF FOUR (4) INNOVIFAST FASTENERS AND SEAM PLATES TO SECURE THE ROOFING MEMBRANE AT THE BASE OF THE PIPE. THEN A 24" X 24" TARGET PATCH OF IKO INNOVI TPO MUST FIRST BE INSTALLED.
  6. HEAT WELD THE BASE OF THE SQUARE SPLIT PIPE BOOT TO THE FIELD MEMBRANE OR TARGET PATCH. A MINIMUM 2.0" WELD IS REQUIRED.
  7. IF INSTALLING OVER A MEMBRANE SEAM, FLASH INTERSECTIONS OF THE BOOT PERIMETER AND MEMBRANE WITH INNOVIFLASH TPO JOINT COVERS.

<b>Title:</b> SQUARE PENETRATION WITH SPLIT SQUARE BOOT AND CLAMP TERMINATION	<b>Detail Number:</b> T-P-6
---	-----------------------------

Issue Date: 8/01/2025	Maximum Warranty Term: 30-Years	Not to Scale
-----------------------	---------------------------------	--------------