



NOTES:

1. REFER TO IKO.COM/COMM FOR THE MOST UP TO DATE INSTALLATION INFORMATION.
2. ANY CARPENTRY OR METAL WORK SHOULD BE DESIGNED AND CONSTRUCTED IN ACCORDANCE WITH LOCAL CODE REQUIREMENTS AND/OR PROJECT SPECIFICATIONS. THESE COMPONENTS SHOULD BE REVIEWED AND APPROVED BY A LICENSED DESIGN PROFESSIONAL. IKO ASSUMES NO RESPONSIBILITY FOR THE INSTALLATION OF THE ASSOCIATED COMPONENTS OR DAMAGE TO THE ROOF SYSTEM DUE TO FAULTY INSTALLATION.
3. REFER TO EXISTING ROOFING MANUFACTURERS' SPECIFICATIONS FOR SURFACE PREPARATION PROCEDURES.
4. IKO INNOVIPRIME TPO PRIMER MUST BE USED TO PREPARE THE MEMBRANE PRIOR TO APPLYING IKO INNOVIFLASH COVER TAPE.
5. CONSTRUCT AND ANCHOR DRIP EDGE IN ACCORDANCE WITH SMACNA RECOMMENDATIONS.
6. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES.
7. FLANGE OF THE METAL DRIP EDGE MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/2" (13MM) FROM WOOD EDGE.
8. CONTACT IKO TECHNICAL DEPARTMENT FOR BALLASTED ROOF SYSTEMS.
9. IF THE FLANGE OF THE METAL DRIP EDGE IS NOT COMPLETELY COVERED WITH IKO INNOVIFLASH COVER TAPER, THEN AN ADDITIONAL PIECE OF COVER TAPE SHALL BE INSTALLED AT THE METAL SPLICE.
10. TO ENSURE FORMABILITY, SLIGHT HEAT-FROM THE SURFACE OF THE TPO PRODUCTS AT STEP-OFFS AND ANGLE CHANGES.

Title: DRIP EDGE WITH TPO COVER TAPE

Detail Number: T-RE-3

Issue Date: 8/01/2025

Maximum Warranty Term: 20-Years

Not to Scale



COMMERCIAL

Specify with Confidence.

